



How to upgrade a new firmware for HTS-1000P

When the control pad has a new firmware, just follow the steps below to upgrade the firmware automatically.


Click the “Upgrading” button.




Control pad will download the latest firmware automatically.



Click “OK” to replace the old one.



Click “Install” to install the new firmware.



There is a dial pad in the lower left corner of the pad screen. This version supports the SIP function so that you could dial to any extension in the IP PBX system.

