

Home Automation

HTS-1000P

10-inch Touch Screen Home Automation Controller



802.11n



PoE



Intercom



AEC



Camera



Z-Wave



1. Verify the Contents Inside the Package Box

The package should contain the following items plus HTS-1000P. If any item is missing or damaged, please contact the seller immediately.



Quick Installation Guide



Wall-mounted Kit



RJ45 Cable




Power Adapter


2. Physical Specifications



Dimensions (W x D x H)	258 x 163 x 24 mm
Weight	620g (gross weight)

10.1 inch Multi Touch Panel



Interface	Description
Volume (+/-)	Press to adjust the volume.
Tab (+/-)	Press to select the next (+) or previous (-) item.
Home	Press to display the HTS-1000P Home Menu.
SD/SDHC	Future Feature.



Interface	Description
Switch	Power switch to turn on/off the HTS-1000P.
Power Jack	<p>The input power is 12V DC.</p> <div style="border: 1px solid orange; padding: 5px;">  <p>Note Use the power adapter included in the package; otherwise, it may damage the unit and result in danger.</p> </div>
HDMI	Future Feature.
Micro USB	Future Feature.
USB Socket	Future Feature.
RJ45 (LAN socket, PoE)	<p>Connect to Router or Hub/Switch It is for connection with 10BASE-T Ethernet, 100BASE-TX or 1000BASE-T Ethernet cabling. This Ethernet port with auto-negotiation protocol can detect or negotiate the transmission speed of the network automatically. Please use Cat5 cable to connect the HTS-1000P to an Ethernet network switch or hub.</p> <div style="border: 1px solid orange; padding: 5px;">  <p>Note ONLY use one power source, either from DC or from 802.3af Power over Ethernet.</p> </div>

3. Prior Installation Requirements

1. The HTS-1000P is for the indoor environment and cannot be installed in the outdoor environment.
2. The IP address can be obtained via router or set the static IP at **Network Setting**.
3. The default setting is below:

Default DHCP Client	On
Default Login User Name	admin
Default Login Password	admin

4. Web UI Specifications



Interface	Description
Janitor	Function of calling janitor.
Intercom	Intercom can be had via the HDP-1100PT to view visitor and talk to him/her upon the door phone call.
Camera	Connected to surveillance cameras, the HDP-1100PT is able for you to view the areas around your house.
Contacts	The contacts that are permitted to communicate with the HTS-1000P.
Control	To control lighting or other Z-Wave devices' switches
Setup	Configuration of the HTS-1000P.

5. Customer Support

Thank you for purchasing PLANET products. You can browse our online FAQ resource and User's Manual on PLANET Web site first to check if it could solve your issue. If you need more support information, please contact PLANET Home Automation support team.

PLANET online FAQs:

<http://www.planet.com.tw/en/support/faq.php?key=HTS-1000P>

Home Automation support team mail address:

support@planet.com.tw



HTS-1000P User's Manual:

<http://www.planet.com.tw/en/support/download.php?model=48703&type=3#list>

Copyright © PLANET Technology Corp. 2015.

Contents are subject to revision without prior notice.

PLANET is a registered trademark of PLANET Technology Corp. All other trademarks belong to their respective owners.

www.PLANET.com.tw