
1. Package Contents

Thank you for purchasing PLANET 5-/8-Port 10/100/1000T industrial Gigabit Ethernet Switch, IGS-501T/IGS-801T. In the following section, the term **"Industrial Gigabit Ethernet Switch"** means the IGT-501T/IGT-801T.

Open the box of the Industrial Gigabit Ethernet Switch and carefully unpack it. The box should contain the following items:



If any of these are missing or damaged, please contact your dealer immediately; if possible, retain the carton including the original packing material, and use them again to repack the product in case there is a need to return it to us for repair.

- 1 -

Switch Fabric 10Gbps 16Gbps Throughput 7.4Mpps 11.9Mpps (packet per second) 9K Jumbo Frame 10/100/1000BASE-T: Cat. 3, 4, 5, 5e, 6 UTP cable Network Cables (100 meters, max.) EIA/TIA-568 100-ohm STP (100 meters, max.) Standards Conformance IEEE 802.3 Ethernet IEEE 802.3u Fast Ethernet Standards IEEE 802.3ab Gigabit Ethernet IEEE 802.3x Full-Duplex Flow Control Compliance IEEE 802.3az Energy-Efficient Ethernet IEEE 802.1p Class of Service Operating: -40~75 degrees C Temperature Storage: -40~75 degrees C Operating: 5% to 90%,

Storage: 5% to 90% (non-condensing)

FCC Part 15 Class A, CE

3.2 LED Indicators

IGS-501T:

LED	Color	Function
P1	Green	Lit to indicate power 1 has power.
P2	Green	Lit to indicate power 2 has power.
Alarm	Red	Lit to indicate either power 1 or power 2 has no power.
1000 LNK/ACT	Green	Lit to indicate the port is successfully connecting to the network at 1000Mbps. Off to indicate that the port is successfully connecting to the network at 10Mbps or 100Mbps. Blinking to indicate that the port is actively sending or receiving data.
10/100 LNK/ACT	Amber	Lit to indicate the port is successfully connecting to the network at 100Mbps or 10Mbps. Off to indicate that the port is successfully connecting to the network at 1000Mbps. Blinking to indicate that the port is actively sending or receiving data.

- 5 -

2. Product Specifications

Model	IGS-501T	IGS-801T		
		193-9011		
Hardware Specifications				
10/100/1000BASE-T Ports	5	8		
Dimensions (W x D x H) 32 x 87 x 135 mm				
Weight	430g	476g		
Power Requirements	9~48V DC, redundant power with reverse polarity protection function, 24V AC power support	12~48V DC, redundant power with reverse polarity protection function, 24V AC power support		
Power Consumption/ Dissipation	2.8 watts/9.5BTU	6.72 watts/23BTU		
Installation	DIN-rail kit and wall-mount ear			
Switch Specifications				
Switch Processing Scheme	Store-and-Forward			
Address Table	2К	4K		
Buffer	4M bits	1.5Mbits SRAM packet buffer		
Flow Control	Back pressure for half duplex IEEE 802.3x pause frame for full duplex			

3. Hardware Introduction

3.1 Switch Front Panel

Humidity

Regulatory

Compliance

The front panel of the Industrial Gigabit Ethernet Switch consists of 5 or 8 auto-sensing 10/100/1000Mbps Ethernet RJ45 ports. The LED Indicators are also located on the RJ45 ports of the Gigabit Ethernet Switch.

- 3 -

Figures 3-1 and 3-2 show the front panels of the industrial Gigabit Ethernet Switches.



Figure 3-1: IGS-501T Front Panel



IGS-801T:


LED	Color	Function
P1	Green	Lit to indicate power 1 has power.
P2	Green	Lit to indicate power 2 has power.
FAULT	Red	Lit to indicate either power 1 or power 2 has no power.
1000 LNK/ACT	Green	Lit to indicate the port is successfully connecting to the network at 1000Mbps. Off to indicate that the port is successfully connecting to the network at 10Mbps or 100Mbps. Blinking to indicate that the port is actively sending or receiving data.
10/100 LNK/ACT	Amber	Lit to indicate the port is successfully connecting to the network at 100Mbps or 10Mbps. Off to indicate that the port is successfully connecting to the network at 1000Mbps. Blinking to indicate that the port is actively sending or receiving data.

- 4 -

3.3 Switch Upper Panel

The upper panel of the Industrial Gigabit Ethernet Switch consists of one terminal block connector within two DC power inputs.

Figures 3-3 and 3-4 show the upper panel of the Industrial Gigabit Ethernet Switch.








Figure 3-4: IGS-801T Upper Panel

- 7 -


3.4 Wiring the Power Inputs

The 6-contact terminal block connector on the top panel of Industrial Gigabit Ethernet Switch is used for two DC redundant power inputs. Please follow the steps below to insert the power wire.




When performing any of the procedures like inserting the wires or tightening the wire-clamp screws, make sure the power is OFF to prevent from getting an electric shock.


1. Insert positive and negative DC power wires into contacts 1 and 2 for Power 1 or 5 and 6 for Power 2.




2. Tighten the wire-clamp screws for preventing the wires from loosening.



- 1. The wire gauge for the terminal block should be in the range between 12 and 24 AWG.
- 2. The IGS-501T power input range is 9V ~ 48V DC and supports 24V AC.
 - 3. The IGS-801T power input range is 12V ~ 48V DC and supports 24V AC.
 - 4 Use one power input when using 24V AC.



2.Alarm relay circuit accepts up to 24V, max. 1A currents.



PLANET Networking & Communication



4. Installation

4.1 DIN-rail Mounting Installation

The DIN-rail is screwed on the Industrial Gigabit Ethernet Switch when out of factory. When you need to replace the wallmount application with DIN-rail application on Industrial Gigabit Ethernet Switch, please refer to the following figures to screw the DIN-rail on the Industrial Gigabit Ethernet Switch. To hang the Industrial Gigabit Ethernet Switch, follow the steps below:



- 11 -

4.2 Wall-mount Plate Mounting



4.3 Side Wall-mount Plate Mounting



You must use the screws supplied with the wallmounting brackets. Damage caused to the parts by using incorrect screws would invalidate your warranty. PLANET Technology Corp. 10F., No. 96, Minquan Rd., Xindian Dist., New Taipei City 231, Taiwan

Warning: This device is compliant with Class A of CISPR 32. In a residential environment this device may cause radio interference. 2350-AH0100-007



5. Customer Support

Thank you for purchasing PLANET products. You can browse our online FAQ resource at the PLANET Web site first to check if it could solve your issue. If you need more support information, please contact PLANET support team.

PLANET online FAQs:

https://www.planet.com.tw/en/support/faq?method=category&c1=3

Support team mail address: support@planet.com.tw

Copyright © PLANET Technology Corp. 2021. Contents are subject to revision without prior notice. PLANET is a registered trademark of PLANET Technology Corp. All other trademarks belong to their respective owners.


- 9 -

3.5 Grounding the Device

Users MUST complete grounding wired with the device; otherwise, a sudden lightning could cause fatal damage to the device.


≟ Earth Ground

Note



3.6 Wiring the Fault Alarm Contact

The fault alarm contacts are in the middle of the terminal block connector as the picture shows below. Inserting the wires, the Industrial Gigabit Ethernet Switch will detect the fault status of the power failure and then form an open circuit. The following illustration shows an application example for wiring the fault alarm contacts.





User's Manual

Industrial 5-/8-Port Gigabit Ethernet Switch

A. A. A. A. A.

▶IGS-501T/IGS-801T



EC Declaration of Conformity

For the following equipment:

*Type of Product : 5/8-Port 10/100/1000T Industrial Gigabit Ethernet Switch

*Model Number IGS-501T IGS-801T

 Produced by: Manufacturer's Name : Planet Technology Corp. Manufacturer's Address : 10F. No.96, Minquan Rd., Xindian Dist., New Taipei City 231, Taiwan, R.O.C.

is herewith confirmed to comply with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility Directive on (2014/30/EU).

For the evaluation regarding the EMC, the following standards were applied:

EN 55032
EN 55024
EN 55035

(2015 + AC:2016) (2010 + A1:2015) (2017)

Responsible for mark	ing this declaration if the:		
🗵 Manufacturer	Authorized representative established within the EU		
Authorized represents	ative established within the EU (if applicable):		
Company Name:	Planet Technology Corp.		
Company Address:	10F., No.96, Minquan Rd., Xindian Dist., New Taipei City 231, Taiwan, R.O.C.		
Person responsible for	r making this declaration		
Name, Surname	Kent Kang		
Position / Title :	Director		

Taiwan

May 28, 2018

PLANET TECHNOLOGY CORPORATION